




OVER and UNDER SHOTGUN



The basic parts of an over and under shotgun. The diagram here shows a sporting gun, but the same parts apply to most other over and under's or side by sides for that matter. The so called safety catch will vary from manufacturer to manufacturer that is to say some will have an 'O' and 'U' other's will just have dots. They can also be manual or automatic (when the gun is broken the catch engages, you usually find these on game guns). On multi choke guns manufacturers will also use different symbols or notches to denote the size (restriction) of their chokes. Fixed chokes are usually marked on the barrels along with chamber lengths and proofing marks.

*** NOTE: The SAFETY CATCH is only a Trigger Lock it DOES NOT make the gun SAFE**


Types of Shotguns that can be used for clay target shooting



Side by Side, mainly used for game shooting.



Over and Under, Used for clay shooting and most other forms of live shooting.



Semi-Automatic, Used for clay shooting and most other forms of live shooting.

Chamber with Safety Flag (Safety Flag denotes the Chamber is Empty).

Most commonly used sizes are 20 bore and 12 bore but can also be found in 410g and 28 bore.